
DirectClock

Keeping the right time on your iSeries and
PCs with DirectClock (FunkUhr)

User Manual



iSeries & Toolmaker - Quality Combined

--

Sales in:

Germany:

TOOLMAKER SOFTWARE GMBH

D-86916 Kaufering, Westendstraße 34

D-86913 Kaufering, Postfach 1361

Phone: (+49) 08191-968-111 Fax: (+49) 08191-968-100

Switzerland:

TOOLMAKER SOFTWARE AG

CH - 8136 Gattikon Obstgartenweg 15

Phone: (+41) 043-305 73 23 Fax: (+41) 043-305 73 49

France:

TOOLMAKER France SARL

F – 6700 Strasbourg 5 Rue du Dr. Maurice Freysz

Phone: (+33) 0810-810 768 Fax: (+33) 0810-810 915

For Germany, Austria, Switzerland:

TOOLMAKER HOTLINE

Phone. (+49) **040-559 19 62** Fax: (+49) 040-559 19 08

For France:

TOOLMAKER HOTLINE

Phone (+33) **0820-820 188**

 User Manual Version 2.41 (printed 25. April 2006),

This manual describes Software Release 2.41

 Layout: Toolmaker Software GmbH, Kaufering

© Copyright: 2006 Toolmaker Software GmbH

Table of Contents

Table of Contents	3
1.0 General Information	5
1.1 Goals and benefits	5
1.2 Terms of use.....	5
2.0 Installing the Hardware Components	7
2.1 Connect the radio clock to the iSeries or PC	7
2.2 Connect the radio clock to a ComServer	8
2.2.1 Connect the ComServer.....	8
2.2.2 Configure the ComServer.....	8
3.0 Installing the Software Components	11
3.1 Install online help system	11
3.2 Update.....	11
3.3 Install DirectClock from iSeries CD-ROM drive	12
3.4 Install DirectClock from PC	12
3.5 Install from download	13
3.6 Configure online help	14
3.6.1 Check application	14
3.6.2 Configure paths	16
3.7 Install online help files	17
3.8 Assign password	17
3.9 Uninstall the iSeries software.....	17
3.10 Install the PC software	18
3.11 PC synchronisation software.....	18
3.12 Uninstall the PC software	18
4.0 Configuration.....	19
4.1 iSeries configuration.....	19
4.2 Configure iSeries for clock on ComServer	21
4.2.1 Host table entry	21
4.2.2 Check ComServer connection.....	21
4.2.3 Configure clock.....	22
4.2.4 Interactive synchronisation.....	23
4.3 Configure iSeries for clock on iSeries V.24.....	23
4.3.1 Create line description CLOCK.....	23
4.3.2 Delete line description CLOCK.....	24
4.3.3 Work with line status CLOCK.....	24
4.3.4 Interactive synchronisation.....	24
4.4 Schedule time synchronisation	25
4.5 Work with job scheduler entries for clock.....	25
4.6 Start clock server.....	26
4.7 End clock server	26
5.0 Administrator.....	27
5.1 PC configuration	27
5.2 PC server program	29
5.3 PC client program.....	30
5.3.1 Automatic synchronisation	30
5.3.2 Manual synchronisation.....	31
6.0 Start Synchronisation from an Application.....	33
7.0 Additional Functions and Program Enhancements	35

8.0 Enhancements and Corrections.....37
8.1 Version 1.9337
8.2 Version 2.0037
8.3 Version 2.3037
8.4 Version 2.4037
8.5 Version 2.4137

9.0 Index.....40

1.0 General Information

DirectClock is a tool that automatically adjusts your iSeries system time using the atomic clock near Frankfurt broadcasting a clock pulse on a DCF long wave radio frequency. The broadcast has a range of approximately 1,500 kilometres from Frankfurt.

Use as a PC radio clock

With the PC software included in shipment and a serial port, you can also use the radio clock on your PCs. The software is installed under Windows. You will find details in a separate document, "PC Radio Clock", provided by HKW.

DirectClock is available in 6 variants:

- To connect to and synchronise a single iSeries
- To synchronise additional iSeries systems in a network
- To synchronise PC systems in a network
- To connect the radio clock hardware to a PC and synchronise iSeries in a network
- To synchronise over the internet using NTP
- To synchronise over a ComServer (remote V.24 interface)

1.1 Goals and benefits

Exact machine and personnel time recording is important if you use shop floor data collection and time recording systems on your iSeries. Inconsistencies between your system time and the actual time can lead to errors.

DirectClock is a combination of a small radio clock connected to an iSeries or PC through a V24 interface and a program that compares the radio clock pulse with your iSeries or PC system time at a defined interval (daily or weekly).

1.2 Terms of use

The software may only be used on the machine indicated in the product order. Changing the machine requires a new password and may incur licence fees. Please ask for a written quote.

2.0 Installing the Hardware Components

If you are using the radio clock hardware, you will first need to connect it when you first install DirectClock. You can do this on

- a free iSeries V24 interface
- a serial port on a PC (not required if you synchronise over the internet)
- a ComServer, which is hardware that allows you to "outsource" the iSeries serial ports to the network (see below for details).

2.1 Connect the radio clock to the iSeries or PC

The radio clock must be located at a place that provides clear reception for the atomic clock's transmissions.

The 9-pole **radio clock connector** fits most PC serial ports.

The radio clock connector must be connected to a special **adapter** included in shipment. The adapter should not be plugged directly into the iSeries interface card. Instead, connect it to the **socket on the thick black iSeries V24 cable**. This is the standard iSeries cable used to operate, for example, an ECS modem .

If you work with a V24 distributor because you want to operate both the radio phone and a modem with a single V24 interface, connect the black V24 cable to the V24 distributor. Two 25-pole cables are normally included with the V24 adapter to replace the black V24 cable used for the clock (see above) or modem.

The radio clock includes **batteries** and is ready to operate as shipped. If the batteries are empty, replace them using the same type by unscrewing the casing at the back of the clock. Polarity is important. Inserting the batteries in the wrong direction can destroy the clock.

Using a thin object, press the hollow on the back of the clock until you feel light resistance. This executes a **Reset** to readjust the clock. Within a period of approximately 5 minutes, the clock attempts to receive the radio signal and adjust the time display. Reception quality during the reset period is indicated by a flashing radio mast symbol and up to 4 horizontal bars. The fewer bars displayed, the poorer the signal.

You may be able to improve reception quality by turning the clock or moving it to another location. Ideally, the front of the clock should be held facing toward Frankfurt.

Once successfully synchronised with the atomic clock, the radio clock displays the current time and date. If unsuccessful, only seconds from 1 to 59 are displayed. A second attempt to reset may be successful. If the

reception at the clock location proves too poor, you will need to extend the iSeries V24 connection so that the clock can be placed at another location. Alternatively, you can connect the radio clock hardware to the iSeries using a ComServer, as described in the next section.

2.2 Connect the radio clock to a ComServer

DirectClock also supports the hardware connection to the ComServer. A ComServer allows you to make one or more V.24 interfaces available in a TCP/IP network.

This means that you can connect the radio clock without using a V24 interface on the iSeries. The iSeries uses TCP/IP to communicate with the ComServer V.24 interface. The ComServer itself acts as a serial port for the radio clock module.

The ComServer is also used with other Toolmaker products. It is ideal for "economising" on V24 interfaces on the iSeries. The ComServer can be maintained at a remote location.

There now follows a step-by-step guide to installing and configuring the hardware.

2.2.1 Connect the ComServer

Step 1: Connect the radio clock to the silver adapter provided. Then connect the adapter to the ComServer with a serial cable.

Important notice:

Always use the cables shipped with your product package. Never connect the radio clock directly to the ComServer.

Step 2: Connect the ComServer to your TCP/IP network.

Step 3: Connect the ComServer to the mains adapter.

2.2.2 Configure the ComServer

Step 1: ComServer IP address:

Before the iSeries can communicate with the ComServer, you must assign the ComServer a free IP address in your network. You can get this from your network administrator.

For a newly shipped ComServer, you can assign the address with the ARP command from a PC in the network. You can also configure the address from a PC using a zero modem cable (not included in delivery) or using a telnet session over port 1111. You will find more information on these options in your ComServer documentation.

With multi-port ComServers, you can enter the IP address on the panel on the ComServer.

Step 2: ComServer configuration menu

After assigning an IP address to the ComServer, you will need to configure the ComServer's COM port. To do this, set up a telnet connection to the ComServer using port 1111 from the iSeries or a PC.

PC: telnet <IP address ComServer, e.g. 192.168.1.55> 1111

iSeries: TELNET RMTSYS('<IP address ComServer, e.g. 192.168.1.55>') PORT(1111)

The ComServer configuration menu is displayed:

```
*****
*      W&T - COM SERVER      *
*****

1. Mode: MONITOR
2. Mode: MENU TYP
3. Mode: COM SETUP
4. Mode: SET TCPIP
5. Mode: INFO
6. Mode: PASSWORD
7. Mode: SAVE
8. Mode: RESET
9. Mode: FLASH/EEP

Press <No.+ ENTER> (q=quit):
```

Select option 3: COM SETUP. A menu of option for the ComServers' serial ports appears.

```
*** Menu: Protocol TCPIP ***

1. Port A

Press <No.+ ENTER> (q=quit):
```

Select the port you want to use for the ComServer.

The menu for configuring serial transfer parameters appears.

```
*** Menu: Protocol TCPIP ***

Port A 300,E,7,2,H
1. Baud:
2. Bit:
3. Parity:
4. Stopbit:
5. Handshake:

Press <No.+ ENTER> (q=quit):
```

Baud=300

Bit=7

Parity=even

Stopbit=2

Handshake=Hardware

Important notice:

The ComServer and radio clock will not be able to communicate if you do not use these settings.

Exit through the menus with q=quit until you are back in the main ComServer menu.

Now select option 7=SAVE to permanently save the changed settings. Confirm the "Save Changes" prompt with "Y". You can now close the telnet session with q=quit.

Important notice:

Remember that changed settings will revert to their default values if you do not save.

3.0 Installing the Software Components

The following is a detailed guide to installing the radio clock.

Note:

The install program creates a library with the name **CLOCK** on your iSeries. If the library already exists, it is first renamed as **CLOCKOLD**. The installation is cancelled if the **CLOCKOLD** library already exists or if the rename fails, for example because objects are in use.

3.1 Install online help system

Toolmaker ships DirectClock with an online help system providing context-sensitive help for the current screen. The online help covers the same topics as the PDF and printed manuals but is much more convenient. The online help system must be installed once before use.

The file **DirectMedia xx.xx english.exe** containing the installation programs is located either on the shipped CD-ROM or on the download area of the Toolmaker homepage.

Enter the command **WRKLIB DIRMEDIA** in a command line to check whether the online help system is already installed in the latest version. The online help system is already installed when the library **DIRMEDIA** with description **DirectMedia/DirectHelp Version 2.73** (or higher) is displayed. In this case the online help system must only be installed, if the version number of the file **DirectMedia xx.xx english.exe** is higher than the version number displayed using the command **WRKLIB**.

The self extracting file **DirectMedia xx.xx english.exe** starts the installation of the online help system. Follow the instructions on screen to install first the iSeries component (library **DIRMEDIA**) and then the PC client. You must install the PC client on each PC on which you want to display online help.

To install the PC client on additional PCs, extract the file **DirectMedia.exe** from the exe file mentioned above (for example with WinZip) and start the installation on each PC by double clicking it.

Hint:

For proper display of the online help the library **DIRMEDIA** must be in your library list. Please ensure this.

3.2 Update

If you are proceeding an update installation, please ensure that nobody is working with the product.

3.3 Install DirectClock from iSeries CD-ROM drive

DirectClock is shipped on a data medium suitable for use on your IBM iSeries system. Both server and PC software are included.

Place the shipped CD-ROM in the CD-ROM drive on your iSeries

Sign on to your iSeries system with a user profile that includes ***ALLOBJ** and ***IOSYSCFG** rights, for example **QSECOFR**.

From a command line, enter the following command:

```
LODRUN OPT01
```


where OPT01 is the name of your CD-ROM drive.

3.4 Install DirectClock from PC

You can also install using the Toolmaker iSeries Installer. The installation is done on a connected PC. You do not need access to the iSeries CD-ROM drive. FTP must be active and you must have the system TCP/IP address and the QSECOFR password.


Insert the CD-ROM into the CD-ROM drive on your PC.

Start this installation variant by double clicking the file **Direct Clock xx.xx english.exe** in the root directory on the CD-ROM. The self-extracting file will guide you step-by-step through the installation process.




1020 – Toolmaker Installer

Read the notes on installation and click "OK" to continue.



1021 – Toolmaker iSeries Installer

To start the installation, click "Setup".



1022 – Installation dialog

Enter the IP address and the QSECOFR password, then click "INSTALL". When the installation is complete, you can display the joblog by clicking "Show iSeries Log". In case of successful installation the remark **"File transfer completed successfully"** is noted at the end of the joblog. Please refer to the Toolmaker hotline for a revision of the installation process if you cannot find this remark. For this purpose save the joblog and send it via email to the Toolmaker hotline.

3.5 Install from download

Download the installation file **Direct Clock xx.xx engl ish.exe** from the "Software – DirectClock – Downloads" section of the Toolmaker website and start the installation by double clicking the .exe file.

The self-extracting file will guide you step-by-step through the installation process. When the installation is complete, you can display the joblog. The last line should read "**Product successfully installed**". Please refer to the Toolmaker hotline for a revision of the installation process if you cannot find this remark. For this purpose save the joblog and send it via email to the Toolmaker hotline.

3.6 Configure online help

Because server, path and folder settings vary from customer to customer, Toolmaker has developed the online help system so that it can be customised to your environment with a few simple steps.

To start configuration, enter

ADDLIBLEDIRMEDIA

GOHELP

The online help menu is displayed.

```
HELP                               DirectHelp Menu
Select one of the following:
1. Work with help users
2. Work with help applications
3. Work with help path configuration

Selection or command
===>

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel
F13=Information Assistant  F16=AS/400 main menu
```

1017 – The DirectHelp menu

3.6.1 Check application

First check whether the application you want configure the online help for, is installed in the DirectHelp help system. To do so use option "Work with Help Applications".

```

Position to . . . . . █

Type choices and press Enter.
  2=Change  4=Delete  7=DirectHelp Wizard  8=Help Tags
 10=Panels 11=Fields 12= Formats

Op Applicat. Description          Activ
_ xxxxxx   Tool                    Yes
    
```

```

Bottom
F3=Exit      F5=Refresh  F6=Create  F10=DirectHelp library list
F11=Display log  F12=Cancel  F14=Import  F24=More keys
    
```

1023 – Work with Help Applications

If your application is not displayed here, it can be imported using the F14 function key.

```

Help import from XML (IMPHLPXML)

Type choices, press Enter.

IFS file . . . . . /Toolmaker/DirectHelp400/xxxxxx.xml █

Help application . . . . . *XML Character value, *XML
Replace application . . . . . *NO *NO, *YES
    
```

```

Bottom
F3=Exit  F4=Prompt  F5=Refresh  F12=Cancel  F13=How to use this display
F24=More keys
    
```

1024 – Help import

IFS file

An application's help definition is stored in a XML file in the iSeries' integrated file system. By default the path /Toolmaker/DirectHelp400/Name of the application.xml is used. If you are not sure about the name of the file to be imported you can display the XML files using the commands **CD / Tool maker / Di r e c t H e l p 4 0 0'** and **WRKLNK**.

Help application

The default option *XML installs the application with the name stored in the XML file.

Replace application

With this you control, whether an existing application will be replaced by the contents from the XML file or not.

3.6.2 Configure paths

For a standard configuration, select option "Work with help path settings".

```
RENGEL                Work with Help Applications                5.04.06 14:55:26

Position to . . . . . █

Type choices and press Enter.
  2=Change   4=Delete   7=DirectHelp Wizard   8=Help Tags
 10=Panels  11=Fields   12=Formats

Op Applicat. Description                                Activ
_ xxxxxx    Tool                                         Yes

F3=Exit      F5=Refresh   F6=Create   F10=DirectHelp library list
F11=Display log F12=Cancel  F14=Import  F24=More keys

Bottom
```

1018 – Help paths

You can use option 2 to change the DirectClock application for all users.

```
.....
:           Add Help Path                                     :
:                                                         :
:   Type choices and press Enter.                           :
:                                                         :
:   Application . . . . . xxxxxx      Name, *ANY             :
:   User/Group . . . . . *ANY        Name, *ANY             :
:   Path . . . . . c:\program files\toolmaker\xxxxx        :
:                                                         :
:   x_____                                                :
:   _____                                              :
:   _____                                              :
:                                                         :
: F3=Exit   F4=Prompt   F12=Cancel                          :
:                                                         :
:.....
```

1019 – Change help path

Application

Name of the application the help file path shall be configured for.

User/Group

Use *ANY to create a setting for all system users.

You can make custom settings for users and groups by using the menu option **Work with help users** to create and group users. With menu option **Work with help path configuration**, you can now replace the user *ANY with the users or groups you have created in order to define custom locations for employees. For example, a rep's local PC, a department server or a branch server. You can find more information on this topic in the manual of the DirectHelp online help system.

You will also find information on configuring the help display for menus and commands in the DirectHelp manual.

Path

Enter the path for the help file here. By default help files are installed in the path c:\Program Files\toolmaker\PRODUCT NAME on the user's client. However the setting can be changed here e.g. to store the help files centrally in the network for all users.

3.7 Install online help files

If you have installed from a download, the online help files are automatically installed. If you install from a CD-ROM, you will find the file **DirectClockhelp.exe** in the root directory. This file contains the Toolmaker online help files. Double click it to install to a local or network folder to which your users have access.

3.8 Assign password

You can test the radio clock without a password for up to 30 days after first installation. After that period, the shipped or faxed password must be entered. This is done with the commands:

ADDLIBLE CLOCK

INSPSW

Now follow instructions for password assignment. To use the full functionality of the radio clock (as both server and client), run the command INSPSW separately for the different license data to be entered.

3.9 Uninstall the iSeries software

To remove the radio clock program from your system, first use options 5 (Delete line description) and 9 (Work with schedule entries) to remove CLOCK objects and entries from other libraries on the iSeries. Exit the radio clock menu with F3. You can then use the commands

RMVCLK CONFIRM(*YES)

to delete the radio clock program and free disk space. The delete will not complete successfully if any jobs are using the CLOCK library, so remember to exit the menu.

3.10 Install the PC software

You will find the file Setup.exe in the folder \PC on the shipped CD. Run this file, for example using Windows Explorer. The PC files are also copied to an iSeries folder CLOCK when you install the software on the iSeries. You can also install the PC software from this folder.

InstallShield menus will guide you through the installation process. By default, radio clock PC programs are installed to C:\Program Files\Toolmaker\FunkUhr.

3.11 PC synchronisation software

If you have connected the radio clock to a PC instead of to the iSeries, the PC acts as a server for other clients. To set the current time on the PC server, run the program Setup.exe in the folder \pc\pcuhr. Follow the install programs' instructions. PC synchronisation is integrated into the Windows Control Panel, where it can be configured using the entry RCCM32.

You can of course also use previously installed modules in addition to the PC synchronisation software. The Toolmaker PC radio clock is used exclusively as a server or client program for synchronising other computers on the network.

3.12 Uninstall the PC software

Remove the software from your PC using Windows by choosing "Start – Settings – Control Panel – Add/Remove Programs".

4.0 Configuration

Display the Radio Clock/400 main menu with the command

STRCLK

The following options are available:

```
CLOCK                Clock/400 Menu                15.02.06
RENGEL                21:45:59

Select one of the following:

    1. Interactive synchronisation
    2. Configure clock
    3.
    4. Create line description
    5. Delete line description
    6. Work with line status
    7.
    8. Schedule time synchronisation (batchjob)
    9. Work with job scheduler entries for clock
    10.
    11. Start clock server
    12. End clock server

Selection or command
==> █

-----
F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel
F13=Information Assistant  F16=AS/400 main menu
```

0001 – The CLOCK menu

4.1 iSeries configuration

To start configuration, select option 2 "Configure clock".

```
CLOCK                Configure Clock                15.02.06
RENGEL                21:46:40

Please make changes and press enter:

Type of communication (Source) . . . : █      V=Radio Clock (V24 port)
                                           N=Network (Clock Server/PC)
                                           T=TCP/IP NTP server (internet)
                                           R=Radio clock using ComServer

Log PC communication . . . . . : N      L=Log (File RPRT), N=No

Hostname/address of clock server . . : NTP3.FAU.DE      (Hostname)
                                           (aaa.bbb.ccc.ddd)

System timezone . . . . . : _25      GMT +01:00 Berlin, Bern, Brus
Zone for daylight saving . . . . . : EUR      Europe, East Europe, USSR
Time for setting daylight saving (S): _2:00      HH:MM
Time for setting daylight saving (W): _3:00      HH:MM
Change QTIMZON of system . . . . . : Y      Y=Yes, N=No
System value QTIMZON for summer . . : QP0100CET2      Value, *SAME
for winter . . . . . : QP0100CET_      Value, *SAME

F3=Exit  F12=Cancel
```

Input fields

Type of communication

The type of communication defines the way the clock is synchronised on an iSeries.

The values allowed are:

- H** for local hardware, indicating that a clock is connected by V24 to the iSeries
- N** for network, indicating that the iSeries is synchronised using another iSeries or a radio clock PC server.
- T** for TCP/IP, indicating that the iSeries uses the NTP protocol to get the current time over the internet
- C** for ComServer, indicating that a radio clock (hardware) connected to a remote V24 interface in the network is used. (The ComServer is an additional hardware module. The next chapter describes ComServer connection and configuration in detail).

PC communication log

You can trace communication between PC and iSeries for test purposes. Enter the value "L" in this field to log communication data to the file RPRT in the library CLOCK.

WARNING:

Don't forget to switch off the trace when you have finished testing. Otherwise all communication data will be written to the RPRT file.

Hostname/address of clock server

If you have set the type of communication to "N", enter the hostname or TCP/IP address of the clock server here. This is another iSeries or a PC.

If you have set the type of communication to "T", enter the TCP/IP address of the NTP time server on the internet you want to use to synchronise the iSeries. We recommend that you use the TCP/IP address 131.173.17.7.

System timezone

Contains the time zone relative to Greenwich Mean Time (GMT). The value for Germany is "25".

Zone for daylight saving

Specify the zone for daylight saving time. The value for Europe is "EUR".

Time for setting daylight saving (S)

Specifies the time at which summer time begins. The value for Germany is "02:00:00" am.

Time for setting daylight saving (W)

Specifies the time at which winter time begins. The value for Germany is "03:00" am.

Adjust UTC offset automatically

Enter "Y" to allow the clock to automatically adjust the system value QUTCOffset. QUTCOffset is used to adjust for time differences, for example in e-mail sent with GMT time.

System value QTIMZON for summer

From V5R3M0, OS/400 assigns a special system value for summer time. The default value for Germany is QP0100CET2.

System value QTIMZON for winter

From V5R3M0, OS/400 assigns a special system value for winter time. The default value for Germany is QP0100CET.

4.2 Configure iSeries for clock on ComServer

The following steps are required only if you have a clock **connected to a ComServer**.

4.2.1 Host table entry

To enable Radio Clock/400 to connect to the ComServer, enter the IP address and hostname (e.g. CLOCK) in your iSeries host table.

To do this, run CFGTCP from an iSeries command line and select option 10, "Work with TCP/IP host table entries". There, you can use option 1=Add to enter the IP address and hostname.

Important notice:

Please check the settings for TCP/IP domain information using option 12 in the CFGTCP menu. The search sequence for hostnames should be set to *LOCAL, so that the system searches for the hostname in the local tables before accessing a DNS server. Consult your system or network administrator before changing this setting. Incorrect settings may seriously impede performance.

4.2.2 Check ComServer connection

Use the PING command on the iSeries to check the connection to the ComServer.

PING <Host table entry for clock, e.g. CLOCK>

4.2.3 Configure clock

To configure Radio Clock/400, please call the Radio Clock/400 menu:

STRCLK

```
CLOCK                      Clock/400 Menu                      15.02.06
RENGEL                      21:45:59

Select one of the following:

    1. Interactive synchronisation
    2. Configure clock
    3.
    4. Create line description
    5. Delete line description
    6. Work with line status
    7.
    8. Schedule time synchronisation (batchjob)
    9. Work with job scheduler entries for clock
    10. Start clock server
    11. End clock server
Selection or command
==> █

F3=Exit  F4=Prompt  F9=Retrieve  F12=Cancel
F13=Information Assistant  F16=AS/400 main menu
```

0001 – The Clock/400 start menu

Select option 2 "Configure clock".

```
CLOCK                      Configure Clock                      15.02.06
RENGEL                      21:46:40

Please make changes and press enter:

Type of communication (Source) . . . : C      V=Radio Clock (V24 port)
                                         N=Network (Clock Server/PC)
                                         T=TCP/IP NTP server (internet)
                                         R=Radio clock using ComServer

Log PC communication . . . . . : N      L=Log (File RPRT), N=No

Hostname/address of clock server . . : COMSERVER_____ (Hostname)
                                         (aaa.bbb.ccc.ddd)

System timezone . . . . . : _25      GMT +01:00 Berlin, Bern, Brus
Zone for daylight saving . . . . . : EUR      Europe, East Europe, USSR
Time for setting daylight saving (S): _2:00  HH:MM
Time for setting daylight saving (W): _3:00  HH:MM
Change QTIMZON of system . . . . . : Y      Y=Yes, N=No
System value QTIMZON for summer . . . : QP0100CET2  Value, *SAME
                                         for winter . . . : QP0100CET_  Value, *SAME

F3=Exit  F12=Cancel
```

0004 – Configure clock, screen 2

In "Type of communication", enter "C" for Radio Clock using ComServer.

If the line description already exists and option 4 is selected, the call ends without an error message when you exit the online text.

4.3.2 Delete line description CLOCK

Option 5 deletes the line description CLOCK from the system. This is required if you want to delete the resource name or to completely remove the clock software from the iSeries.

4.3.3 Work with line status CLOCK

Allows you to display the line status for CLOCK if you encounter problems calling option 1. The command WRKCFGSTS *LIN is executed.

4.3.4 Interactive synchronisation

After making the configuration settings described below, you can use this option at any time to check the system value QTIME against the correct time from the radio clock in an interactive dialog, where you can use F10 to synchronise.

The line description CLOCK is activated or the time is retrieved from the clock server. The program then attempts to receive the pulse from the radio clock. If successful, system values and clock data are displayed.

```
.....
: █                               Clock/400                               :
:                                                                           :
:   Set system time by pressing F10.                                     :
:                                                                           :
:           System                NTP Server                             :
:           S44T0223              NTP3.FAU.DE                          :
:   Date . . . . 15.02.06        15.02.06                             :
:   Time . . . . 21:47:45        21:47:45   Winter                    :
:   UTC offset   +01:00          +01:00                               :
:                                                                           :
:                                                                           :
:                                                                           :
:   F3=Exit   F10=Set time                                             :
:                                                                           :
:.....
```

0005 – Interactive synchronisation

The display is refreshed once per second. If there is any discrepancy, you can use F10 to adjust the system value QTIME. This process can take up to 15 seconds, depending on the performance of your iSeries. Despite the time lost updating the system values, the program attempts a synchronisation with second accuracy. Once the system value has been updated, the "lost"

seconds are made up in a rapid sequence on the screen. The screen is then again refreshed once per second.

An error message is displayed if the program fails to contact the clock.

You can regularly and automatically execute the synchronisation process by creating a job schedule entry with option 8.

4.4 Schedule time synchronisation

You can use option 8 to create a job schedule entry that automatically synchronises the system value QTIME and the clock. This runs the operating system command ADDJOBSCDE.

The parameters for this command might look like this:

Frequency	FRQ	*WEEKLY
Schedule date or	SCDDATE	*NONE
Schedule day	SCDDAY	*ALL
Schedule time	SCDTIME	040000

Using these parameters, the iSeries regularly and automatically synchronises QTIME and clock time, in this example every day at 4 o'clock in the morning. You can display the schedule status at any time with option 9, which also allows you to change and delete.

Note:

Because the synchronisation updates the system date, please ensure that you don't schedule the job for shortly before or after midnight. This is because if the program may attempt to update directly before the date is changed, it could interfere with the automatic system date change.

Important notice:

The system time is changed only if the difference between iSeries system time and clock time is **less than or equal to 90 minutes**. This interval ensures that daylight savings time is supported, and that extreme variances do not interfere with iSeries operation.

4.5 Work with job scheduler entries for clock

Use option 9 to monitor automatic synchronisation between the iSeries and the radio clock. This runs the command **WRKJOBSCDE**, which displays a list of scheduler entries for change or delete.

During **automatic clock synchronisation**(in batch), a **message** is displayed in the QSYSOPR queue if problems are encountered receiving clock signals. Possible causes are: clock has lost contact, contact is poor or irregular, battery is low, product code has expired. V.24 communications problems are output to QSYSOPR as system error messages.

4.6 Start clock server

You can use option 10 to start the clock server if you use your local iSeries as a server for other iSeries or PC systems. The server runs the job CLOCKSERV in the QINTER subsystem and answers requests for synchronising with clients.

To ensure that it is always active, we recommend that you include the clock server in your QSTRUP start program (after starting TCP/IP!).

Note that CLOCKSERV is restarted with the commands

```
ADDLIB LIB(CLOCK)
```

```
STRCLKSRV
```

if you have ended and restarted the QINTER subsystem.

4.7 End clock server


You can use option 11 to end the active clock server.

5.0 Administrator

Before you can start working with the PC component of the radio clock, some synchronisation work with the clock administrator is required.

5.1 PC configuration

To begin, choose "Start – Program Files - Funkuhr - FunkUhr Administrator".



0006 - FunkUhr Administrator - Common

Input fields

Protocol

Select the type of communication with the iSeries – either TCP/IP or, if you work with a router connection, (e.g. Netsoft Router), 32-bit Router.

Access

First synchronisation after

Enter the number of minutes after which the clock is synchronised in client mode; that means in which sequence the PC gets the time from the iSeries. The default value is "2", indicating that the PC retrieves and synchronises the time from the Series every two minutes.

Synchronisation each

Enter the number of minutes after which the clock is synchronised in client mode; that means in which sequence the PC gets the time from the iSeries, after it is started. The default value is "0", indicating that the synchronisation takes place immediately after the start.


Automatic start of client

If you synchronise the PC time using an iSeries clock server, allows you to automatically load the PC client program on system start. Check this option to automatically start the client program.

Automatic start of server

If you synchronise the iSeries time using a PC clock server, allows you to automatically load the PC server program on system start. Check this option to automatically start the server program.

If you have selected "TCP/IP" as the type of communication, now click the "TCP/IP" tab to make further settings. Otherwise click "OK" to save your settings.



The screenshot shows the 'FunkUhr Administrator' dialog box with the 'TCP/IP' tab selected. The 'Standard system' field contains '192.168.100.10'. The 'TCP/IP Address of system' field contains '#', with a 'Change' button to its right. The 'Service port number' field contains '50010'. There are two radio buttons for signon information: 'Use Signon informations from windows logon' (unselected) and 'Use specified signon informations' (selected). Below these are fields for 'Username' (containing 'RENGEL') and 'Password' (containing 'xxxx'). A checked checkbox labeled 'Case Sensitive Passwords' is also present. The 'Time Out' field contains '0'. At the bottom are buttons for 'OK', 'Cancel', 'Apply', and 'Help'.

0007 - FunkUhr Administrator - TCP/IP settings

Input fields

Standard system

Your iSeries TCP/IP name

TCP/IP address of system

Enter your iSeries TCP/IP address in the format indicated. Your iSeries TCP/IP address can be found in the file "HOSTS" in the Windows folder or with the AS/400 command "CFGTCP" and option 1 "Work with TCP/IP interfaces".

Service port number

The PC communicates with the iSeries through a TCP/IP socket program. The related server program runs on the iSeries. In order to connect, the service port number must be the same as the service table entry on the iSeries. The default value is port number "50010". If this port number is already in use, or if you wish to use a different number, you must ensure that the port numbers on the PC and the iSeries match. To check the service table entries on the iSeries, use the OS/400 commands "CFGTCP", option 21 "Configure related tables" and option 1 "Work with service table entries".

Username

Enter the name of your user profile here, or the name of another user authorised to query the related files.

Password

The password you enter here is encrypted and saved.

Folder for password

The folder where user and password is stored in encrypted form.

Timeout

The default value is "0". You may leave this setting as is.

Note

When you have made your settings, first click "Apply" and then "OK".


5.2 PC server program

If you want to run the radio clock on a PC as a server program, allowing your iSeries to retrieve the time from the PC, the PC server program must be started before the iSeries requests the time. For information on iSeries settings, please refer to chapter "iSeries configuration".

If you have checked the "Automatic start of server" option during connection configuration, the server is automatically started each time the PC is booted.


You can also start the server manually by choosing "Start – Program Files - FunkUhr - FunkUhr Server". The server program is now ready to pass the time when it receives a request from an iSeries client.

An icon is displayed in the taskbar while the server is active.



0008 – Clock server is active

You can display server program processes by right clicking the icon and selecting "Show".




0013 – Server program log

5.3 PC client program

If you want to run the radio clock on a PC as a client program, so that the PC retrieves the time from an iSeries, the PC client program must be started to allow synchronisation.

You can start the client manually by choosing "Start – Program Files - FunkUhr – Activate FunkUhr Client. The time will now be requested from the iSeries at the interval defined in administrator. Note that the job CLOCKSrv must be active in the subsystem QINTER or QBASE to allow iSeries synchronisation on the server system.


An icon is displayed in the taskbar while the server is active.



0009 - Icon

5.3.1 Automatic synchronisation


When the client is active, the PC requests the time from the iSeries at the interval defined in administrator and synchronises the PC time with the time passed from the iSeries. You can view synchronisation processes by right clicking the clock client icon in the taskbar and selecting "Show".



0010 – The PC client

5.3.2 Manual synchronisation

When the PC client is active, you can start synchronisation either by displaying the client as described above and then choosing "Synchronise", or by right clicking the radio clock PC client icon in the taskbar and choosing "Manual synchronisation". Click the "Synchronise" button in the following window for time synchronisation.



0011 - Manual synchronisation on the PC

6.0 Start Synchronisation from an Application

If you want to start synchronisation of the system value QTIME and the clock from an application, first ensure that the library CLOCK has been added to the job library list.

In a CL program, the call would look like this:

```
CALL PGM(TKC110CL) PARM('4')
```

In an RPG program, it looks like this:

```
CALL 'TKC110CL'  
  
PARM '4'          ACTI ON 1
```

Because the call may end abnormally in some situations, you may want to consider including monitoring messages such as MONMSG in CL or a reference number at position 56 in RPG.

Batch applications with Radio Clock/400 always produce both a joblog and a message in the QSYSOPR message queue. You can use both sources for error analysis.

Important notice:

The system time is changed only if the difference between iSeries system time and clock time is **less than or equal to 90 minutes**. This interval ensures that daylight savings time is supported, and that extreme variances do not interfere with iSeries operation.

7.0 Additional Functions and Program Enhancements

The program now only uses the **time received** from the clock to change the system time. The system date is no longer changed.

Important notice:

The system time is changed only if the difference between iSeries system time and clock time is **less than or equal to 90 minutes**. This interval ensures that daylight savings time is supported, and that extreme variances do not interfere with iSeries operation.

A batch joblog is always created to enable analysis should errors occur during automatic synchronisation of the system time. You can use log objects (CLKSAVx) to check the clock data record if required.

You can force time conversion with line 7.00 QDATE=Y in source file TKC110TT in file QDDSSRC in library CLOCK (not recommended).

8.0 Enhancements and Corrections

The following is a summary of enhancements and corrections.

8.1 Version 1.93

- Client PCs can receive the time from an iSeries, allowing them for example to synchronise workstations or servers.
- Other iSeries systems can now retrieve and synchronise the time from a central iSeries with a connected clock.
- iSeries systems can now retrieve and synchronise the time from PC systems with a connected clock.

8.2 Version 2.00

- The PC client now supports manual synchronisation.

8.3 Version 2.30

- Synchronisation via TCP/IP and NTP protocol as well as ComServer implemented.

8.4 Version 2.40

- Adjusted for enhancements to time conversion in OS/400 Version 5 Release 3
- Integration of English, French, Italian.
- Integration of online help with DirectHelp

8.5 Version 2.41

- Correction of the installation routine for Upgrade of very old versions
- Correction of the synchronisation window on the Client

9.0 Index

A

Access	27
Adapter	7
Adjust UTC offset automatically	21
Administrator	27
Assign clock password	17
Atomic clock	5
Automatic start of client	28
Automatic start of server	28
Automatic synchronisation	30

C

CFGTCP	29
Check application	14
CLKSAVx	35
CLOCK	11, 33
CLOCKOLD	11
CLOCKSERV	26
ComServer	20
Configure online help	14
Configure paths	16
CRTLINASC	24

D

Delete line description for radio clock	24
Difference	26, 33, 35

E

ECS-Modem	7
End clock server	26
Extending the V24 connection	8

F

First synchronisation after	27
Folder for password	29
Functions	35

G

GO HARDWARE	24
-------------------	----

H

Help application	16
Hostname/address of clock server	21

I

IFS file	15
INSPSW	17

Install DirectHelp online help system	11
Install from download	13
Install from iSeries CD-ROM	12
Install from PC	12
Install online help files	17
Interface card	7
iSeries configuration	19

J

Job scheduler entries	26
-----------------------------	----

L

Line description	24
Line status	24

M

Manual synchronisation	31
------------------------------	----

N

NTP protocol	20
--------------------	----

P

password	17
Password	29
PC client program	30
PC communication log	20
PC configuration	27
PC radio clock	5
PC server program	29
PC synchronisation software	18
Program enhancements	35
Protocol	27

Q

QTIME	24, 33
-------------	--------

R

Reception	7
Reception quality	7
Replace application	16
Reset	7
resource name	24
RMVCLK	17
RPRT	20

S

Schedule time synchronisation	25
Service port number	29
Shop floor data collection	5
Standard system	28
Start clock server	26
STRCLKSRV	26
Synchronisation	7, 25, 26, 33

Synchronisation each28
 Synchronisation work.....27
System date35
 System time.....5, 35
 System timezone21

T

TCP/IP address.....29
 Time for setting daylight saving (S).....21
 Time for setting daylight saving (W)21
 Time recording..... 5
Timeout29
 Toolmaker Radio Clock18
 Type of communication20

U

Uninstall from iSeries17
 Uninstall from PC18
Username29

V

V24 interface.....5, 7

W

WRKJOBSCDE26

Z

Zone for daylight saving21